

## **Installation Instructions for 6"- 10" CCX Vent Piping**

1. Have lower wall vent pipe poured into vault top or side as close to centered over comb air valve as possible.
2. Once vault top is placed on vault, attach upper 180 deg vent pipe with SS flg bolt kit provided. If top install.
3. Mount combo air valve and isolation valve to pipe connection.
4. Expose top connection of combo valve by removing top cover.
5. Attach flanged connection supplied with vent pipe to combo valve cut to fit to leave small gap between wall pipe and valve pipe.
6. Use flexible coupling to join the two pipe sections.
7. Attach 3/8 tube (supplied) to two compression fittings supplied with kit to small ARV and tapped boss on side of lower vent pipe.
8. To test vent integrity, close isolation valve below combo air valve, attach flange or bushing (supplied by others) to 180 degree connection pressure to 5psi for one minute to insure no possible cross connection with water system.
9. Remove testing materials and install screen assembly supplied with kit.