

Installation instructions for 3/4" – 1" CCX Vents

CCX vent will include the UL Check Valve to install on outlet of the Air valve (except CAV's) the compression connections, galv reducer, above grade vent pipe and bug screen. All threaded connections shall use Teflon tape to insure air tight fit. To assemble, thread CV in outlet of ARV and thread 3/8" compression adapter in to outlet of CV. Determine where the above grade pipe is to be installed and cut tubing to appropriate length. Thread 2nd compression adapter into bushing and thread bushing into bottom of above grade vent pipe. Form up a 2' x 2' box to pour a concrete slab around wall collar on vent pipe, making sure that the wall collar is in the center of the concrete thickness. Let concrete set up and remove forms. To test for tightness pump up to 5psi and watch for 1 minute to insure air tight assembly. Then install bug guard by treading into FIP connection on end of vent.