

Installation instructions for 2" CCX Vents

CCX vent will include the connections, PVC reducer, above grade vent pipe and bug screen. All threaded connections shall use Teflon tape to insure air tight fit. To assemble, thread PVC MIPxSW connection into the outlet of the valve. Determine where the above grade pipe is to be installed and cut PVC Pipe (not included) to appropriate length. Thread 2nd MIPxSW adaptor into 2"x 1-1/2" bushing and thread bushing into bottom of above grade vent pipe. Form up a 2' x 2' box to pour a concrete slab around wall collar on vent pipe, making sure that the wall collar is in the center of the concrete thickness. Let concrete set up and remove forms. To test for tightness pump up to 5psi and watch for 1 minute to insure air tight assembly. Then install bug guard by treading into FIP connection on end of vent.